## **Assembly Manual:**



1 Content: 1 Stroller frame, 2 Front wheels, 2 Rear wheels, 1 Rear crossbar, 1 Cup-holder



2 Begin to unfold the stroller by releasing the side hook.



3 Pull the frame up and the stroller will click into place.



4 Turn stroller over to headstand position.



To insert the rear wheel, press the wheel button while gently sliding the axle into the wheel's axle end. You will feel the wheel lick into place.

To remove the rear wheels, press the wheel button while gently sliding the wheel away from the axle.



6 Insert the front wheel by sliding 7 the axle into the wheel end.
Make sure the front wheel is locked into place.



Fix the cup holder with groove.



Adjustable handle height by pushing button.



To rotate the gear of front wheel to lock the front wheel assembly in the straight position or allow the front wheel assembly to swivel.

## Elegant Retro I

## Folding steps:



1 Push the right black button of the tube and pull up the both tubes at one time.



2 Lay down the frame to fold the stroller.



3 Lock the frame by the side hook.

