## **Assembly Manual:**



1 Content: 1 stroller frame, 1 carrier bag, 1 front wheels. 1 rear wheel frame, 2 rear wheels, 1 cup holder.



- 2 1) Press the metal dome on the outer side of the wheel hub with the rear wheel frame.
  - 2) Insert the axle of the wheel into its hollow axle. Push the wheel until it locks. Fit the second wheel on another side in the same way.



3 Hold the assembled rear wheel set and make the break rod toward to the outward direction. Insert the assembled rear wheel set into the both sides of tube on the frame as picture shown. Check the both sides of rear wheels are secure.



screw cap of the front wheel (without removing screws)



1) Release the 2) Place the front wheel on the front fork.



3) Position the front wheel which placed on the front fork to aim at the hole of both sides then lock the screw cap.



4) Pull the fixed handle forward tight then installment completely.



5 The view after assembled all wheels.



6 Lift up the handle until both side of the joins click.



7 Place the cup holder to the frame as shown.



8 Secure the frame by capping the hooks on the frame bolts on both sides of the stroller.



Push the black switch button which placed at the bottom of front wheel to the right, the front wheel can be rotated 360 degrees.

Inno Pet



2) Push the black switch button which placed at the bottom of front wheel to the left, then the front wheel fixed.



## Comfort Stroller

## Folding steps:



1 Unzip the front mesh. Unlock the safety hooks (both sides)



2 Press the red button. Hold the button and twist it downwards.



3 Lay down the handle to fold the stroller.



4 Place the front wheel flat as picture shown.



Lock the frame by the side hook.

Failure to unlock the safety hooks (both sides) before folding will cause the front safety bar to break. This type of user error is NOT covered in the product warranty.